

**BONDERITE M-CR 1200S  
AERO/ CHROMATE COATING  
(KNOWN AS ALODINE 1200S)**

Issued 11/7/2014

**INTRODUCTION**

BONDERITE M-CR 1200S AERO (known as ALODINE 1200S) is a powdered chemical used to produce a protective coating on aluminum which minimizes corrosion and provides an improved bond for paint. Surfaces treated with the BONDERITE M-CR 1200S AERO process range in color from a light iridescent golden to tan.

BONDERITE M-CR 1200S AERO coating chemical listed on Qualified Product List QPL-81706, is an approved material to produce Class 1A and Class 3 coatings, bare or painted, in accordance with Military Specification MIL-DTL-5541.

**OPERATING SUMMARY**

<u>Chemical:</u>	<u>Bath Preparation per 100 gallons</u>
BONDERITE M-CR 1200S AERO	6.3 pounds
BONDERITE M-CR 1200S AERO (Brush)	12.5 pounds (2 oz. per gal.)

  

<u>Operation and Control:</u>	
ALODINE Coating Chemical Titration	6.0 ml
Concentration Range	5.0 ml to 19.0
pH	1.3 to 1.8
Temperature	70° to 100° Fahrenheit
Time	15 seconds to 3 minutes

**THE PROCESS**

The complete process for the BONDERITE M-CR 1200S AERO treatment normally consists of the following steps:

- A. Cleaning
- B. Water rinsing
- C. Deoxidizing (required for heavily oxidized surfaces)
- D. Water rinse (required when deoxidizing is used)
- E. Treating with the BONDERITE M-CR 1200S AERO processing solution
- F. Water rinsing
- G. Drying

# BONDERITE M-CR 1200S AERO/ CHROMATE COATING

(KNOWN AS ALODINE 1200S)

---

## MATERIALS

BONDERITE M-CR 1200S AERO  
Nitric Acid  
Testing Reagents and Apparatus

## EQUIPMENT

Process tanks and housings should be fabricated from 300 series alloy stainless steel, such as 304L or 316L. The 316L being preferred for maximum tank life. In all cases approved welding techniques must be used.

### Brush Application:

Acid-resistant (wood, rubber, stainless steel, or plastic) buckets, troughs, or other suitable containers are used to hold the diluted BONDERITE M-CR 1200S AERO coating chemical solution. Lead, glass, tin or galvanized iron should not be used. Storing the solution in mild steel containers will result in a slow decomposition of the solution.

Ordinary spray equipment (satisfactory for short or infrequent application) will be attacked slowly by BONDERITE M-CR 1200S AERO coating chemical. This may be minimized by thoroughly flushing with water immediately after use. For continuous use, plastic or stainless steel cups and nozzles should be used in spray equipment.

### Spray and Immersion Application:

Process piping and pumps should be constructed of 316 or 304 stainless steel alloys. Various formulations of plastic pipe may be used with recommended support spacing, Schedule-80 being generally recommended. PVC Type I is limited to maximum process temperatures of 140° Fahrenheit. CPVC and PP may be used up to a maximum process temperature of 190° Fahrenheit. PVDF may be used for all expected operating temperatures and may reduce the rate of scale buildup in process piping. The nozzles should be fabricated from 316 stainless steel.

Heat exchanger plates should be polished 316 stainless steel. If gas fired burner tubes are used, they should be made of Schedule-80 mild steel pipe or equivalent. All process circulation pump seals, valve seats, door seals, etc., which come into contact with the process solution and occasional acid equipment cleaners, should be FKM or PTFE. EPDM may be used, but its life will be shorter.

Chemical feed pump parts and other elastomers which may come into contact with the concentrated replenishing chemical should be FKM or PTFE. Again, EPDM may be used, but its life will be shorter.

Support equipment available from Henkel for this process includes chemical feed pumps, level controls, transfer pumps and bulk storage tanks.

## SURFACE PREPARATION

### Cleaning:

All metal to be treated with the processing solution must be free from grease, oil and other foreign matter before the treatment. A complete line of cleaners is available under the RIDOLINE trademark and our representative will recommend the proper one for each installation.

### Water Rinsing:

After cleaning, the metal must be thoroughly rinsed with water. The rinse should be overflowed continuously at a rate which will keep it clean and free from scum and contamination.

---



# BONDERITE M-CR 1200S AERO/ CHROMATE COATING (KNOWN AS ALODINE 1200S)

Deoxidizing:

Aluminum with corrosion products or heavy oxide coated surfaces should be treated with a deoxidizer prior to the conversion coating treatment step. The deoxidizing step should follow the water rinse and should itself be followed by a separate water rinse. Our representative can recommend the correct deoxidizer to be used.

**TREATING WITH THE BONDERITE M-CR 1200S AERO PROCESSING SOLUTION**Buildup (Immersion or Spray):

Fill the tank about three-fourths full with cold water for each 100 gallons of final solution volume add 6.3 pounds of BONDERITE M-CR 1200S AERO (known as ALODINE 1200S) and circulate until thoroughly mixed. Finally, add sufficient water to bring the solution up to the working level and then heat the operating temperature.

Buildup (Brush):

Mix 2 oz. of BONDERITE M-CR 1200S AERO coating chemical per gallon of water (this is equivalent to 15 g of BONDERITE M-CR 1200S AERO coating chemical per liter of solution). Stir well until the powder is dissolved.

Note: A small amount of insoluble material may settle out of solution; this can be disregarded. Use an acid-resistant container when preparing the solution.

Operation:

Time: 15 seconds to 3 minutes.

Temperature: 70° to 100° Fahrenheit.

Operational Recommendations:

Each alloy reacts with the BONDERITE M-CR 1200S AERO coating chemical bath to produce a coating that is characteristic of the alloy. For the treating time selected, the bath should produce a light, iridescent golden to tan colored coating on aluminum. If the desired coatings are not obtained, add BONDERITE M-CR 1200S AERO in 1/4 oz increments (up to a maximum of 3.0 oz/gal) until satisfactory coatings are produced. As the concentration of BONDERITE M-CR 1200S AERO is increased, the bath will have to be titrated to determine the operating titration. The desired coatings may also be obtained by adjusting the pH.

The initial charge and replenishment data contained herein are normal for most installations..

If the coating is powdery, the cause may be one or more of the following:

- A. The work has been improperly cleaned and/or rinsed.
- B. The concentration of the coating chemical(s) in the bath is too high.
- C. The BONDERITE M-CR 1200S AERO bath has become contaminated with phosphates, sulfates, chlorides, or some other contaminant (analysis required).
- D. The coating time is too long.
- E. The bath temperature is too high.
- F. The pH of the bath is too low for the concentration selected.

If the coating is too light, the cause may be one or more of the following:

- A. The treating time is too short
- B. The concentration of BONDERITE M-CR 1200S AERO in the bath is too low.
- C. The temperature of the bath is outside the specified range.
- D. The pH of the bath is outside the specified range.

**BONDERITE M-CR 1200S  
AERO/ CHROMATE COATING  
(KNOWN AS ALODINE 1200S)**

---

**TESTING AND CONTROL**

Never pipet by mouth, use a pipet filler.

Concentration:

Pipet a 5 ml sample into an iodimetric flask and dilute to approximately 100 ml with water. Add 1/2 teaspoon (approximately 1 g) of Reagent 2 and agitate to dissolve. Add about 10 ml of Reagent Solution 49 in 5 ml increments to the lip of the flask, raising the stopper slightly after each addition to allow the acid to run into the flask. Rinse the lip several times with water and replace the stopper.

After the sample has settled for approximately one minute, titrate with Titrating solution 104 until a straw color is obtained. Do Not rezero the burette. Add several ml of Indicator 10 and continue the titration until the blue-black color disappears. The ml of Titrating Solution 104 used is the bath concentration value in points (ml).

Concentration range: Within  $\pm 1$  point (ml) of the value which gives the desired results.

To increase the value 1 point (ml): Add 1 lb of BONDERITE M-CR 1200S AERO per 100 gallons.

Concentration: 1 ml of titrant = 1.73 mg/ml of hexavalent chrome in Alodine 1200S

pH Determination:

A pH determination should be made after each replenishing addition. The optimum pH for this bath is between 1.3 to 1.8.

NOTE: The pH of the BONDERITE M-CR 1200S AERO (known as ALODINE 1200S) bath is controlled by the addition of 1/2 pint of concentrated nitric acid for every 2 to 4 pounds of BONDERITE M-CR 1200S AERO (known as ALODINE 1200S) used. It is recommended that no large bulk additions to nitric acid be made. The nitric acid additions should be made along with the required BONDERITE M-CR 1200S AERO additions.

In certain instances, the pH of the bath will continue to decrease several hours after an addition of nitric acid (as the solution seeks equilibrium). Accordingly, small adjustments in pH should be made allowing 15 minutes to elapse before subsequent adjustment.

If the amount of nitric acid specified is insufficient to maintain the bath pH, the pH will rise causing a reduction in color intensity of the coating. If this occurs, increase the amount of nitric acid per addition (in small increments to a maximum of 1.5 pints per 2 to 4 pounds of BONDERITE M-CR 1200S AERO) until the color intensity of the coating is maintained.

**AFTER TREATMENT**Water Rinsing:

After the conversion coating treatment, the work is thoroughly rinsed in cold water. The rinse should be continuously overflowed and the overflow should be regulated with the rate of production so that the main body of the rinse never becomes excessively contaminated.

Drying:

The treated articles should be dried immediately after the post treatment. Enough heat usually remains from a hot post treatment to cause heavy gauge articles to dry satisfactorily. If the post treatment is not heated or the articles do not dry satisfactorily, an indirect fired drying unit or any other means which will not contaminate the treated surface with fumes, oil, or partially burned gases may be used. If an oven or other heat source is used, the temperature of the metal surface should not be permitted to exceed 150° Fahrenheit to maintain optimum corrosion resistance.

---



**BONDERITE M-CR 1200S  
AERO/ CHROMATE COATING  
(KNOWN AS ALODINE 1200S)**

---

Products with cavities or pockets which trap moisture should be blown dry with clean, compressed air. Moisture spatters should be dried with clean cloths.

Dried, unfinished parts should not be handled. If handling if necessary, plastic or clean (often changed) cotton gloves should be used.

**STORAGE REQUIREMENTS**

BONDERITE M-CR 1200S AERO is a powdered product and is unaffected by freezing.

**WASTE DISPOSAL INFORMATION**

Applicable regulations covering disposal and discharge of chemicals should be consulted and followed.

The processing bath is acidic and contains chromium and ferricyanide. Waste treatment and neutralization will be required prior to discharge to the sewer. (Refer to Waste Treatment Information Bulletin WT1004, available on request.)

**PRECAUTIONARY INFORMATION**

When handling the chemical products used in this process, the first aid and handling recommendations on the Material Safety Data Sheet for each product should be read, understood and followed.

The following precaution should be observed during the operation of the BONDERITE M-CR 1200S AERO coating bath:

Adequate ventilation should be provided for the process area. Operators must not breathe ALODINE coating bath vapors. Open containers in a well ventilated area. Keep containers closed when not in use.

The processing bath contains chromic acid in excess of 0.1% when prepared as recommended. The following statement, or one similar to it, should be included as part of the process tank labeling.

"Possible cancer hazard based on tests with laboratory animals.  
Overexposure may create cancer risk."

Refer to the Material Safety Data Sheet for additional information.

## BONDERITE M-CR 1200S AERO/ CHROMATE COATING (KNOWN AS ALODINE 1200S)

Testing Reagents and Apparatus  
(Order only those items which are not already on hand)

<u>Code</u>	<u>Quantity</u>	<u>Item</u>
89000-202** .....	2 .....	Beaker, Plastic, 150-ml
41579*** .....	1 .....	Bottle, Plastic, Clear w/Medicine Dropper, 2 oz
592477 .....	1 .....	Buret Assembly, 25-ml Automatic
89000-252** .....	1 .....	Cylinder, Graduated, 50-ml
89090-780** .....	2 .....	Flask, Iodimetric, 250-ml
592401 .....	250 ML.....	Indicator 10 (soluble starch solution)
89003-516** .....	2* .....	Pipet, 5-ml, Measuring
53497-009** .....	1 .....	Pipet Filler
53600-108** .....	1 .....	Pitcher, Graduated, Plastic
592413 .....	450 GM.....	Reagent 2 (Potassium Iodide)
592438 .....	2.5 L .....	Reagent Solution 49 (C.P. HCl)
30250**** .....	1 .....	Thermometer, Floating
592416 .....	1.0 L .....	Titration Solution 104 (0.1N Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> )
++++++ .....	1 .....	Electrometric pH Meter

\*Includes one more than actually required, to allow for possible breakage.

\*\* VWR Part # – vwr.com or 800-932-5000

\*\*\*Consolidated Plastics Part #

\*\*\*\*Thomas Scientific Part #

Henkel Corporation | 32100 Stephenson Highway | Madison Heights, MI 48071  
PHONE: (248) 583-9300 | FAX: (248) 583-2976 | www.henkeln.com/

#### Trademark usage

Except as otherwise noted, all trademarks in this document are trademarks of Henkel Corporation in the U.S. and elsewhere. ® denotes a trademark registered in the U.S. Patent and Trademark Office.

The data contained herein are furnished for information only and are believed to be reliable. We cannot assume responsibility for the results obtained by others over whose methods we have no control. It is the user's responsibility to determine suitability for the user's purpose of any production methods mentioned herein and to adopt such precautions as may be advisable for the protection of property and of persons against any hazards that may be involved in the handling and use thereof. In light of the foregoing, **Henkel Corporation specifically disclaims all warranties expressed or implied, including warranties of merchantability or fitness for a particular purpose, arising from sale or use of Henkel Corporation's products. Henkel Corporation specifically disclaims any liability for consequential or incidental damages of any kind, including lost profits.** The discussion herein of various processes or compositions is not to be interpreted as representation that they are free from domination of patents owned by others or as a license under any Henkel Corporation patents that may cover such processes or compositions. We recommend that each prospective user test his proposed application before repetitive use, using this data as a guide. This product may be covered by one or more United States or foreign patents or patent applications.

